

## Installing the Thermometer Probe

(WHEN DIGITEMP IS ORDERED AS OPTIONAL EXTRA)

1. Drill 3/8" diameter hole thru partition wall panel at location as shown.
2. Insert freezer thermometer probe thru hole and attach to adjacent freezer wall.
3. Carefully insert sealant insulation into hole around probe lead wire.
4. Seal hole completely using silicone sealant.
5. Secure thermometer lead and probe with clips and screws supplied in hardware box.

