

- Secure ADPT Frame Hard Board Retainer (with Heater Wire and Hard Board installed) to bottom interior of Door Cap with #8 x ½" screws. ENSURE SCREWS DO NOT DAMAGE HEATER WIRE. If required, Heater Wire Assembly black & white leads (at the top of the Door Cap) can be pulled to remove excess wire length at bottom of door cap.
- 4 If required...install ADPT Frame Sweeper Gasket
- **5** If required...install Interior Wiper Gasket.
- **6** Using wire nuts, connect black and white Heater Wire Assembly leads to existing power source at top of Door Cap.
- **7** Reinstall Crossover Cord assembly.