



Installation Instructions for Drip Edge for a Bally Aluminum Roof

NOTE: THE DRIP EDGE SHOULD BE INSTALLED UNDER THE DOWNWARD FLANGE OF THE ALUMINUM ROOF. THE METAL SCREWS WHICH FASTEN THE DOWN FLANGE OF THE ALUMINUM ROOF ALSO ATTACHES THE DRIP EDGE.

