



Installing Door Trim on 5" Panels

1. Apply a small bead of caulking on the interior of the trim piece.
2. Place trim between the 4" door hook side and the 5" adjacent vertical pin side so the flange is directed towards the adjacent panel. Speed-Lok the two panels. Thus fixing the trim in position.
3. Place the provided panel gasket on the interior pin side of the door.
4. Remove the panel gasket on the interior hook side of the adjacent 5" vertical.
5. As in step 2 place the trim piece so the flanges is towards the 5" panel, push in position and Speed-Lok.

