

## Installation Instructions for Bally's 2" Special Purpose Door

1. Prepare Rough Opening
2. Typical Door Jamb
3. Installing Header
4. Installing Vertical Jamb (strike side)
5. Installing Vertical Jamb (hinge side)
6. Checking Rabbet Dimension
7. Securing Jambs
8. Applying Weather Strip
9. Mount Wiper Gasket

